

FLAT-BACK RAIN BARREL / BARIL À DOS PLAT

INSTRUCTIONS

September / Septembre 2011
Revision /Révision 04





Spigot Assembly

1.1 Screw spigot (end with hexagonal feature) into pre-threaded opening in front of the Flat Back Rain Barrel.

1.2 Thread spigot until the hex face touches the barrel. Do not over tighten beyond the point where another turn is not possible.

1.3 Adjust spigot until vertical relative to the barrel.

TO PREVENT STRIPPING BARREL THREADS, LAY THE BARREL FLAT BACK DOWN TO INSTALL THE SPIGOT.

Screen Installation

2.1 Locate the screen and press/fit into recessed section on top of the Flat-Back Rain Barrel.

2.2 Press down firmly onto the screen to secure screen to barrel.

NOTE: If you plan to leave your Rain Barrel outside over the winter it is very important to winterize your Flat-Back Rain Barrel as follows:
a) Drain your Rain Barrel.
b) Remove the screen and place inside the Rain Barrel.
c) Turn the Rain Barrel upside down and set in desired location, preferably in a garage or basement. Failure to comply with these winterization instructions may result in a voided warranty.

NOTE: NO MORE THAN A 3 FOOT STANDARD GARDEN HOSE SHOULD BE USED FOR PROPER WATER FLOW.

Installation du robinet

1.1 Visser le robinet (le côté avec le butoir hexagonal) dans le trou fileté au bas du baril.

1.2 Continuer à fileter le robinet jusqu'à ce que le butoir s'emboîte parfaitement à la surface plate. Ne pas trop serrer.

1.3 Ajuster le robinet jusqu'à ce qu'il soit vertical relativement au baril.

Afin d'éviter un mauvais alignement, coucher le baril pour installer le robinet

Installation de l'écran protecteur

2.1 Localiser l'écran et insérer dans la section encastrée du baril.

2.2 Appuyer fermement sur le cadre de l'écran pour verrouiller l'écran au baril.

NOTE : Si vous planifiez laisser votre Baril à l'extérieur pendant l'hiver, il est très important de l'aménager pour l'hiver. La garantie sera nul si cette procédure n'est pas suivie :
a) Vider votre baril
b) Enlever l'écran protecteur et le placer à l'intérieur du baril
c) Tourner le baril à l'envers et placer à l'endroit désiré, de préférence.

Note: Afin d'assurer un bon débit d'eau, utiliser un boyau standard de 3' ou moins.

RTS Companies Inc. warrants its products to be free from defects in materials and workmanship under normal use and service for the period of one year. All warranty periods begin on the date of invoice. This warranty does not cover defects, which are merely cosmetic, but is limited to defects, which result in structural failure, including structural failure due to material corrosion or deterioration.

This warranty does not cover damage due to vandalism, abuse, lack of maintenance or improper installation. RTS Standard Terms and Conditions apply.

RTS Companies Inc offre une période de garantie de 1 an à partir de la date de la vente, contre les défauts de fabrication. La garantie s'applique uniquement si le produit est utilisé à l'intérieur des limites d'utilisation normale, telles que décrites dans le manuel d'instructions. Une copie complète de la politique de garantie peut être obtenue par téléphone 1-800-663-2803 ou www.rtshomeaccents.ca

RTS Companies Inc. | 1027 Industrial Place, P.O. Box 179, St. Clements, Ontario N0B 2M0 | 1-800-663-2803
RTS Companies US Inc. | 2900 Industrial Park Drive, Austinburg, Ohio 44010 | 1-440-275-3077